



BT-16

## **INVERTED BUCKET STEAM TRAP**

### GENERAL FEATURES

water hammer.

The same diameter steam traps have different orifice diameters for evacuation of variable loads.

Bucket Steam Inverted Traps evacuate the condensate when it appears that's why their heat efficiency is high.

When the steam enters the steam trap, steam moves upwards to the bucket. Steam traps close with the closing system which is fixed to bucket so steam exist in the bucket. Because of the heat loss at steam body, steam becomes condensate and bucket moves downward. Steam trap opens with the valve system which is fixed to the bucket and condensate is evacuated.

### **Applications**

- Heat exchangers Vulcanizing equipment
- Heating units
- Drying coils
- Radiator panels - Rubber presses
  - Main fuel tank heaters
  - Horizontal lines


Ayvaz BT-16 Inverted Bucket Steam Ayvaz BT-16 inverted bucket system has to be filled Traps have high strength construction halfway with water at the first operation. Orifice and structure so they are durable for counterpart are made of hardened stainless steel. Strainers should be used before the steam traps.

#### Connection:

Threaded and Flanged

### **Pressure Range:**

Max. 16 bar




Material List						
No	Part Name	Material				
1	Body	GGG 40				
2	Adjustment Pipe	Stainless Steel AISI 304				
3	Filter	Stainless Steel 304				
4	Body Plug	St 37-2				
5	Cover Gasket	Grafit				
6	Bushing	Stainless Steel AISI 304				
7	Cover	GGG 40				
8	Fixed Seat	Stainless Steel AISI 304				
9	Screw	Stainless Steel AISI 304				
10	Seat	Stainless Steel AISI 304				
11	Valve	Stainless Steel AISI 304				
12	Valve Seat	Stainless Steel AISI 304				
13	Washer	Stainless Steel AISI 304				
14	Locking Washer	Stainless Steel AISI 304				
15	Float	Stainless Steel AISI 304				
16	Cover Plug	St 37-2				
17	Bolt	8.8				

#### **Installation and Precautions:**


- Clean the residues, dust and other foreign matter in the pipeline before installation.
- Install in an easily accessible place.
- Install the device close to the device.
- Make the pipeline slopped so that water can flow through the gravity into the condensate.
- Set up a bypass pipe.
- Make sure that the output line does not rise to prevent backflow.
- Make sure that it is connected horizontally.


Dia.	Applicable differential pressure (bar)
1/2" - 3/4" - 1"	5.4/8.5/15.5
Body	GGG 40
Cover	GGG 40
Inner Part and Float	Stainless Steel
Max. Working Pressure	16 bar
Max. Working Temp.	220 °C
Connection	Threaded



(16)

### THREADED TYPE SPECIFICATIONS







Dia.	А	В	ØC	ØD	ØD1	L	AA
1/2"	153	81	98	72	45	127	46
3/4"	153	81	98	72	45	127	46
1"	183	103	98	72	55	127	56

All dimensions are in "mm".

## FLANGED TYPE SPECIFICATIONS





DN	А	В	ØC	ØD	ØD1	L	Øk	Øg	b	Ødxn
15	153	81	98	72	95	170	65	46	14	Ø14x4
20	153	81	98	72	105	180	75	56	16	Ø14x4
25	183	103	98	72	115	195	85	65	16	Ø14x4


All dimensions are in "mm".

#### Storage and Handling:

#### Consider the following recommendations to maximize product performance.

- Do not overload on it.
- Do not store the product in dusty or high humidity areas.
- Do not allow foreign substances to enter the product.
- Sand particles, deposits etc. that may come into contact with the gasket during pipe installation or cleaning. Please do not allow such materials.
- Close valves 1 and 2 to clean the bypass line.
- Do not perform a water pressure test on a valve which may cause water leakage or malfunction.

SIGN	REASON	SOLUTION			
	the orifice is clogged with dirt	Dismantling and cleaning			
No Discharge	If the pressure used is higher than the condensate pressure	Replacement with condensate at proper pressure			
	If there is insufficient discharge	Exchange with sufficient capacity steamtrap			
Low Discharge	Extreme counter pressure and insufficient working pressure difference ( $\Delta P$ )	The inlet / outlet outlet pressure / pipe is reconsidered.			
	If the filter at the inlet of the steamtrap is blocked	Dismantling and filter cleaning			
Steam Leak	If there is dirt between disk and seat	Disassembly, disc and seat cleaning			
	Worn disk and seat	Disc and seat replacement			
	Defective by-pass valve	Change the by-pass valve			



# **BT-16 INVERTED BUCKET STEAM TRAP**



#### **HEAD OFFICE - FACTORY**

Atatürk Sanayi Bölgesi Hadımköy Mahallesi Mustafa İnan Caddesi No: 44 Arnavutköy - İSTANBUL Tel: +90 212 771 01 45 (pbx) | Fax: +90 212 771 47 27 info@ayvaz.com | www.ayvaz.com

Cona Caserta/Italy

Tel: +39 0823 187 3988 rmolaro@ayvaz.com

**Ayvaz Germany** Viernheim/Germany Tel: +49 62046014399

Kiev/Ukraine Tel: +380 44 390 57 57 germany@ayvaz.com

Ayvaz Ukraine

info@ayvaz.com.ua

Tricorr Warsaw/Poland Tel: +48 530 030 810 +48 533 603 335 tricorr@tricorr.eu

Ayvaz Azerbaijan Baku/Azerbaijan Tel: +99 (455) 579-84-32 ahayatov@ayvaz.com

**Ayvaz Egypt** Cairo/Egypt Tel: +20 122 819 78 29 andrew.eid@ayvaz.com

Ayvaz Gulf Dubai/U.A.E

Tel: +971 563550822 : Tel: +86 152 5830 7361 +971 501306871 : msahin@ayvaz.com +971 501306871 mideast@ayvaz.com :

Ayvaz China Ningbo/China msahin@ayvaz.com

Ayvaz Kazakhstan LLP : Ayvaz N Almaty/Kazakhstan Tel: +7 (727) 327 97 57 info\_kz@ayvaz.com

Isperih/Bulgaria

Ayvaz Serbia : Belgrade/Serbia Tel: +359 8431 27 32 : Tel: +381 61 658 70 52 : ggursoy@ayvaz.com office@ayvaz-n.eu yakbiyik@ayvaz.com Tel: +84 89 8508345

: Ayvaz Vietnam HCMC/Vietnam Ayvaz Americas Rhode Island/USA Tel: +1 401 737 8380 americas@ayvaz.com